

## VX-8E Unlock

---

The following document it's only for the Europeans models not for US models

**VX-8E TX Mod 120-173.995MHz 220-221.995MHz 400-469.995MHz 300-576MHz**

- 1 Power on
- 2 set MODE
- 3 # 21 CWID
- 4 CWID (on)
- 5 Push “MODE”
- 6 Turn DIAL to A, push “MODE”
- 7 Turn DIAL to H, push “MODE”
- 8 repeat 6-7, to type in “AH029M”
- 9 Push “SET” to get out of set mode
- 10 Power off
- 11 Push HM/RV + MENU power on
- 12 Turn Dial to choose MODE \*\*\*
- 13 Push Funtion/W
- 14 Power off
- 15 Power on

**Elias-Greece**