

M-100 Optional Power Supply Kit

Installation

1. Attach the Power Adapter Cable and the Microphone cable (supplied with M-100) together, and then connect them between the modular "MIC Jack" on the M-100 microphone, and the "MIC" jack on the transceiver.
2. Connect the Power cable between the AC adapter and Power Adapter Cable.

! Caution



- This Power Supply Kit is for use only with the M-100 microphone.
- When the M-100 Optional Power Supply is utilized, the M-100 microphone power is no longer controlled with the transceiver ON/OFF switch.
- Do NOT use any cables or any AC adapters other than those supplied with this Kit.

Specifications

Input Voltage: AC 100 V - 240 V

Output Voltage: DC 5.0 V

Maximum Output Current: 500 mA



YAESU MUSEN CO., LTD.