

This Manual is provided by  
***CBTricks.com***

Someone who wanted to help you repair your equipment put together this information.

## Cobra1000GTL Parts List

If you would like to help us put more manuals online support us.

**If you would like to help with this project let us know.**

Supporters of CBTricks.com paid for the hosting so you would have this file.

CBTricks.com is a non-commercial personal website was created to help promote the exchange of service, modification, technically oriented information, and historical information aimed at the Citizens Band, GMRS (CB "A" Band), MURS, Amateur Radios and RF Amps.

CBTricks.com is not sponsored by or connected to any Retailer, Radio, Antenna Manufacturer or Amp Manufacturer, or affiliated with any site links shown in the links database. The use of product or company names on my web site is not endorsement of that product or company.

If your company would like to provide technical information to be featured on this site I will put up on the site as long as I can do it in a non-commercial way.

The site is supported with donation from users, friends and selling of the Galaxy Service Manual CD to cover some of the costs of having this website on the Internet instead of relying on banner ads, pop-up ads, commercial links, etc. Thus I do not accept advertising banners or pop-up/pop-under advertising or other marketing/sales links or gimmicks on my website.

ALL the money from donations is used for CBTricks.com I didn't do all the work to make money (I have a day job). This work was not done for someone else to make money also, for example the ebay CD sellers.

All Trademarks, Logos, and Brand Names are the property of their respective owners.

This information is not provided by, or affiliated in any way with any radio or antenna Manufacturers.

**Thank you for any support you can give.**

# BILL OF MATERIAL FOR COBRA 1000GTL

CIRCUIT SYMBOL	DESCRIPTION	DYNASCAN PART NO.
<b>SEMICONDUCTORS</b>		
IC-1	Integrated Circuit,	TA7222P, AF POWER ..... 307-143-9-003
IC-2,3	Integrated Circuit,	TA7310P, VCO, TX MIX ..... 307-133-9-004
IC-4	Integrated Circuit,	μPD2816C, PLL ..... 307-145-9-001
IC-701	Integrated Circuit,	TM4801P, CLOCK ..... 307-149-9-001
TR-4	Field Effect Transistor,	2SK104-H..... 182-055-9-001
TR-3,21	Field Effect Transistor,	2SK19-BL ..... 182-037-9-001
TR-16,17,24,702,802	Transistor,	2SA733-P ..... 177-020-9-001
TR-15	Transistor,	2SC458-C ..... 176-048-9-002
TR-1,8,9,13,19,23,203,801,26	Transistor,	2SC945A-Q ..... 176-062-9-001
TR-201	Transistor,	2SC1061-C ..... 172-044-9-001
TR-18,202	Transistor,	2SC1096-3ZL ..... 172-024-9-001
TR-2	Transistor,	2SC1674-L ..... 176-081-9-002
TR-5,6,7,14,22,25	Transistor,	2SC1675-L ..... 176-065-9-001
TR-11	Transistor,	2SC2028-B/20 ..... 172-038-9-001
TR-10	Transistor,	2SC2029-B/10..... 172-038-9-002
TR-12	Transistor,	2SC2076-C ..... 176-060-9-004
D-6,7,11,12,16,28	Diode,	1N60-AM ..... 150-014-9-001
D-9,10	Diode,	1N60-P ..... 150-006-9-001
D-4	Diode,	1S34 ..... 150-016-9-001
D-5	Diode,	1S2075-K ..... 151-028-9-001
D-1,2,3,15,17,19,20,24,27,801,802	Diode,	1S2076 ..... 153-008-9-001
D-201,202,203,204	Diode,	GM-3Y ..... 151-079-9-001
D-13,26	Diode,	SR1K-1 ..... 151-040-9-003
D-205	Diode, Zener,	BZ-162 ..... 152-057-9-001
D-206	Diode, Zener,	WZ-071..... 152-075-9-001
D-21	Diode, Zener,	XZ-051 ..... 152-088-9-001
D-25	Diode, Zener,	XZ-086 ..... 152-089-9-001
D-701	Diode, Zener,	CZ-092 ..... 152-051-9-001
D-501	Diode, LED	TLR325, CH LED ..... 158-023-9-001
D-702	Diode, LED	TLR2077, CLOCK LED ..... 158-023-9-002
D-18	Diode, Varicap,	1S2687-D ..... 153-008-9-001
D-14	Diode, Varicap,	1S2688-EA ..... 154-004-9-001
<b>INDUCTORS</b>		
L-1	Coil,	LA-029 ..... 060-023-9-001
L-25	Coil,	LA-088 ..... 066-019-9-002
L-6	Coil,	LA-106 ..... 060-019-9-002
L-2	Coil,	LA-138 ..... 046-024-9-001
L-19	Coil,	LA-166 ..... 066-025-9-005
L-4	Coil,	LA-180 ..... 060-024-9-001
L-23	Coil,	LA-182 ..... 060-024-9-003
L-24	Coil,	LA-198 ..... 060-029-9-001
L-18	Coil,	LA-201 ..... 046-024-9-002
L-7	Coil,	LA-204 ..... 046-024-9-003
L-8	Coil,	LA-207 ..... 046-025-9-001
L-17	Coil,	LA-208 ..... 060-029-9-004
L-21	Coil,	LA-217 ..... 060-030-9-003

**CIRCUIT  
SYMBOL**

**DESCRIPTION**

**DYNASCAN  
PART NO.**

**INDUCTORS (Continued)**

L-5	Coil,	LA-274 .....	046-025-9-002
L-20	Coil,	LA-275 .....	046-025-9-003
L-3	Coil,	LA-277 .....	046-025-9-004
L-10,16	Coil,	LC-018 .....	041-056-9-003
L-13	Coil,	LC-019 .....	041-088-9-001
L-14	Coil,	LD-012 .....	041-069-9-004
L-12	Coil,	LE-088 .....	041-104-9-001
L-11	Coil,	LE-089 .....	041-104-9-002
L-9	Bead Core,	LD-071 .....	044-043-9-006
L-15	Bead Core,	LD-087 .....	044-048-9-003
L-301	Bead Core,	LD-088 .....	044-051-9-001
L-26	Microinductor,	LZ-001, 10 $\mu$ H .....	041-105-9-001
L-22	Microinductor,	LZ-001, 100 $\mu$ H .....	041-062-9-002
T-301	Power Transformer,	TF-149 .....	065-144-9-001
T-1	Output Transformer,	TF-129 .....	061-039-9-001
T-2	Choke Coil,	TF-083 .....	042-021-9-001

**SEMI-FIXED & VARIABLE RESISTORS**

VR-1	Resistor, Semifixed,	RV-189	300 ohm B.....	008-345-9-001
VR-201	Resistor, Semifixed,	RV-189	500 ohm B .....	008-342-9-001
VR-4	Resistor, Semifixed,	RV-189	20K ohm B .....	008-316-9-003
VR-6	Resistor, Semifixed,	RV-189	5K ohm B .....	008-316-9-004
VR-2	Resistor, Semifixed,	RV-189	30K ohm B .....	008-331-9-001
VR-5	Resistor, Semifixed,	RV-189	50K ohm B .....	008-316-9-002
VR-3	Resistor, Semifixed,	RV-189	100K ohm B .....	008-316-9-001
VR-301	Resistor, Variable,	1K ohm B, RV-287,	RF GAIN ...	008-350-9-001
VR-302	Resistor, Variable,	50K ohm A, RV-333,	TONE .....	008-347-9-004
VR-303	Resistor, Variable,	50K ohm A, RV-320,	VOL .....	008-347-9-002
VR-304	Resistor, Variable,	50K ohm B, RV-331,	SQ .....	008-347-9-003
VR-305	Resistor, Variable,	5K ohm B, RV-074,	SWR-CAL ..	008-350-9-002
VR-306	Resistor, Variable,	20K ohm B, RV-039,	DELTA-TUNE..	008-350-9-003
VR-307	Resistor, Variable,	5K ohm A, RV-293,	MIKE GAIN.....	008-344-9-005

**FIXED RESISTORS**

R-603,604	Resistor, Metal Film,	22 ohm	2W	$\pm$ 10% .....	013-038-9-003
R-95	Resistor, Metal Film,	200 ohm	2W	$\pm$ 10% .....	013-015-9-002
R-93	Resistor, Metal Film,	15 ohm	1W	$\pm$ 10% .....	013-038-9-001
R-401,402,403	Resistor, Metal Film,	47 ohm	1W	$\pm$ 10% .....	013-038-9-002
R-702,112	Resistor, Metal Film,	150 ohm	1W	$\pm$ 10% .....	013-039-9-001
R-82	Resistor, Metal Film,	22 ohm	1/2W	$\pm$ 10% .....	011-125-9-005
R-601,602	Resistor, Metal Film,	220 ohm	1/2W	$\pm$ 10% .....	013-039-9-002
R-701	Resistor, Cement,	150 ohm	7W	$\pm$ 5% .....	013-039-9-003
R-44	Resistor, Solid,	1K ohm	1/2W	$\pm$ 10% .....	013-039-9-004
R-301	Resistor, Solid,	1.5M ohm	1/2W	$\pm$ 10% .....	013-039-9-005
R-49	Resistor, Carbon Film,	4.7 ohm	1/2W	$\pm$ 5% .....	002-102-5-479
R-201	Resistor, Carbon Film,	220 ohm	1/2W	$\pm$ 5% .....	002-102-5-221
R-303	Resistor, Carbon Film,	2.2M ohm	1/2W	$\pm$ 5% .....	002-102-5-225
R-110	Resistor, Carbon Film,	56 ohm	1/4W	$\pm$ 5% .....	002-102-5-560
R-103	Resistor, Carbon Film,	2.2 ohm	1/8W	$\pm$ 5% .....	002-108-5-229
R-50	Resistor, Carbon Film,	3.9 ohm	1/8W	$\pm$ 5% .....	002-108-5-399
R-8,11,22,27,51	Resistor, Carbon Film,	100 ohm	1/8W	$\pm$ 5% .....	002-108-5-101
R-24	Resistor, Carbon Film,	470 ohm	1/8W	$\pm$ 5% .....	002-108-5-471

**CIRCUIT  
SYMBOL**

**DESCRIPTION**

**DYNASCAN  
PART NO.**

**FIXED RESISTORS (Continued)**

R-204	Resistor, Carbon Film, 680 ohm 1/8W	±5%	002-108-5-681
R-203,205	Resistor, Carbon Film, 820 ohm 1/8W	±5%	002-108-5-821
R-64,202	Resistor, Carbon Film, 1.2K ohm 1/8W	±5%	002-108-5-122
R-68	Resistor, Carbon Film, 2.2K ohm 1/8W	±5%	002-108-5-222
R-94,1	Resistor, Carbon Film, 2.7K ohm 1/8W	±5%	002-108-5-272
R-97	Resistor, Carbon Film, 3.3K ohm 1/8W	±5%	002-108-5-332
R-69,104	Resistor, Carbon Film, 4.7K ohm 1/8W	±5%	002-108-5-472
R-120	Resistor, Carbon Film, 6.8K ohm 1/8W	±5%	002-108-5-682
R-108	Resistor, Carbon Film, 5.6K ohm 1/8W	±5%	002-108-5-562
R-46,109,39	Resistor, Carbon Film, 10K ohm 1/8W	±5%	002-108-5-103
R-98,21	Resistor, Carbon Film, 22K ohm 1/8W	±5%	002-108-5-223
R-57	Resistor, Carbon Film, 100K ohm 1/8W	±5%	002-108-5-104
R-804	Resistor, Carbon Film, 68 ohm 1/4W	±5%	002-104-5-680
R-92	Resistor, Carbon Film, 470 ohm 1/4W	±5%	002-104-5-471
R-47	Resistor, Carbon Film, 1 ohm 1/8W	±5%	002-108-5-109
R-85,99	Resistor, Carbon Film, 10 ohm 1/8W	±5%	002-108-5-100
R-48,55	Resistor, Carbon Film, 22 ohm 1/8W	±5%	002-108-5-220
R-73	Resistor, Carbon Film, 33 ohm 1/8W	±5%	002-108-5-330
R-52	Resistor, Carbon Film, 47 ohm 1/8W	±5%	002-108-5-470
R-6,72,74	Resistor, Carbon Film, 56 ohm 1/8W	±5%	002-108-5-560
R-86	Resistor, Carbon Film, 82 ohm 1/4W	±5%	002-104-5-820
R-16,65,83,122,134	Resistor, Carbon Film, 100 ohm 1/8W	±5%	002-108-5-101
R-63	Resistor, Carbon Film, 180 ohm 1/8W	±5%	002-108-5-181
R-26	Resistor, Carbon Film, 220 ohm 1/8W	±5%	002-108-5-221
R-107	Resistor, Carbon Film, 470 ohm 1/8W	±5%	002-108-5-471
R-45	Resistor, Carbon Film, 560 ohm 1/8W	±5%	002-108-5-561
R-20,43,501,502,503, 504,505,506,507,508, 509,510,511,512,513, 514	Resistor, Carbon Film, 680 ohm 1/8W	±5%	002-108-5-681
R-42,59	Resistor, Carbon Film, 820 ohm 1/8W	±5%	002-108-5-821
R-17,19,96,100,105,132, 7,802	Resistor, Carbon Film, 1K ohm 1/8W	±5%	002-108-5-102
R-61	Resistor, Carbon Film, 1.5K ohm 1/8W	±5%	002-108-5-152
R-10,14,18,53	Resistor, Carbon Film, 2.2K ohm 1/8W	±5%	002-108-5-222
R-114,803	Resistor, Carbon Film, 1.2K ohm 1/8W	±5%	002-108-5-122
R-79,66	Resistor, Carbon Film, 1.8K ohm 1/8W	±5%	002-108-5-182
R-25,117	Resistor, Carbon Film, 3.3K ohm 1/8W	±5%	002-108-5-332
R-35	Resistor, Carbon Film, 3.9K ohm 1/8W	±5%	002-108-5-392
R-15,67,115,705,91	Resistor, Carbon Film, 4.7K ohm 1/8W	±5%	002-108-5-472
R-4,23,101	Resistor, Carbon Film, 5.6K ohm 1/8W	±5%	002-108-5-562
R-9,54,62,81	Resistor, Carbon Film, 6.8K ohm 1/8W	±5%	002-108-5-682
R-3,13,34,37,56,76,88,106, 121,124,126,70,119,706	Resistor, Carbon Film, 10K ohm 1/8W	±5%	002-108-5-103
R-133	Resistor, Carbon Film, 15K ohm 1/8W	±5%	002-108-5-153
R-32,33,71,77,5,75	Resistor, Carbon Film, 22K ohm 1/8W	±5%	002-108-5-223
R-2	Resistor, Carbon Film, 27K ohm 1/8W	±5%	002-108-5-273
R-80,84	Resistor, Carbon Film, 12K ohm 1/8W	±5%	002-108-5-123
R-36,40	Resistor, Carbon Film, 39K ohm 1/8W	±5%	002-108-5-393
R-38,128,60,102	Resistor, Carbon Film, 47K ohm 1/8W	±5%	002-108-5-473
R-28,31	Resistor, Carbon Film, 56K ohm 1/8W	±5%	002-108-5-563
R-29,30,78	Resistor, Carbon Film, 82K ohm 1/8W	±5%	002-108-5-823
R-127,129,180	Resistor, Carbon Film, 100K ohm 1/8W	±5%	002-108-5-104
R-801	Resistor, Carbon Film, 390K ohm 1/8W	±5%	002-108-5-394
R-123,704,41	Resistor, Carbon Film, 1M ohm 1/8W	±5%	002-108-5-105

**CIRCUIT  
SYMBOL**

**DESCRIPTION**

**DYNASCAN  
PART NO.**

**FIXED RESISTORS (Continued)**

R-125	Resistor, Carbon Film, 2.2M ohm 1/8W	±5%	.....	002-108-5-225
R-118	Resistor, Carbon Film, 1.5M ohm 1/8W	±5%	.....	002-108-5-155

**CAPACITORS**

C-128	Capacitor, Electrolytic,	0.47 μF	50V	.....	022-157-9-001
C-29,59,,93,152	Capacitor, Electrolytic,	1 μF	50V	.....	022-157-9-002
C-204	Capacitor, Electrolytic,	2200 μF	35V	CZ-048	..... 022-175-9-004
C-39,153	Capacitor, Electrolytic,	2.2 μF	25V	.....	022-158-9-002
C-45,72	Capacitor, Electrolytic,	4.7 μF	25V	.....	022-157-9-003
C-116	Capacitor, Electrolytic,	220 μF	25V	.....	022-175-9-003
C-1,37,57,89,67,135	Capacitor, Electrolytic,	10 μF	16V	.....	022-157-9-004
C-36	Capacitor, Electrolytic,	22 μF	16V	.....	022-157-9-005
C-134	Capacitor, Electrolytic,	33 μF	16V	.....	022-157-9-006
C-115,205	Capacitor, Electrolytic,	220 μF	16V	.....	022-163-9-003
C-74	Capacitor, Electrolytic,	470 μF	16V	.....	022-076-9-008
C-43	Capacitor, Electrolytic,	1000 μF	16V	.....	022-158-9-004
C-73,120,126,150 154,804	Capacitor, Electrolytic,	47 μF	10V	.....	022-160-9-002
C-114,801,121	Capacitor, Electrolytic,	100 μF	10V	.....	022-157-9-008
C-112	Capacitor, Electrolytic,	470 μF	6.3V	.....	022-158-9-008
C-91,92	Capacitor, Tantalum,	2.2 μF	16V	±20%	..... 027-033-9-001
C-41	Capacitor, Tantalum,	4.7 μF	16V	±20%	..... 027-026-9-004
C-25,70	Capacitor, Tantalum,	10 μF	10V	±20%	..... 027-025-9-001
C-129	Capacitor, Aluminum,	0.1 μF	16V	±20%	..... 022-177-9-001
C-22	Capacitor, Myler,	0.001 μF	25V	±20%	..... 025-134-9-001
C-127,76,27	Capacitor, Myler,	0.0022 μF	25V	±20%	..... 025-134-9-002
C-31	Capacitor, Myler,	0.0047 μF	25V	±20%	..... 025-134-9-003
C-38	Capacitor, Myler,	0.0033 μF	25V	±20%	.....
C-32,33,40,44,124	Capacitor, Myler,	0.01 μF	25V	±20%	..... 025-137-9-002
C-95,122	Capacitor, Myler,	0.022 μF	25V	±20%	..... 025-137-9-006
C-18,19	Capacitor, Myler,	0.039 μF	25V	±20%	..... 025-134-9-006
C-77	Capacitor, Ceramic Disc,	0.1 μF	25V	+80% -20%	BC.. 020-210-9-008
C-20	Capacitor, Ceramic Disc,	1 pF	50V	±0.25pF	SL.. 020-190-9-001
C-51	Capacitor, Ceramic Disc,	2 pF	50V	±0.25pF	SL.. 020-187-9-001
C-80	Capacitor, Ceramic Disc,	8 pF	50V	±0.5pF	SL.. 020-213-9-001
C-98	Capacitor, Ceramic Disc,	15 pF	50V	±10%	SL.. 020-180-9-010
C-303,163,62	Capacitor, Ceramic Disc,	22 pF	50V	±10%	SL.. 020-180-9-011
C-99,100	Capacitor, Ceramic Disc,	39 pF	50V	±10%	SL.. 020-190-9-007
C-49	Capacitor, Ceramic Disc,	56 pF	50V	±10%	SL..
C-55,165,79	Capacitor, Ceramic Disc,	100 pF	50V	±10%	SL.. 020-180-9-016
C-166	Capacitor, Ceramic Disc,	150 pF	50V	±10%	SL.. 020-180-9-014
C-107,52,61	Capacitor, Ceramic Disc,	220 pF	50V	±10%	SL.. 020-180-9-019
C-84,53	Capacitor, Ceramic Disc,	330 pF	50V	±10%	SL.. 020-181-9-008
C-702	Capacitor, Ceramic Disc,	560 pF	50V	±10%	SL.. 020-213-9-003
C-167	Capacitor, Ceramic Disc,	680 pF	50V	±10%	SL.. 020-187-9-007
C-71,75,83,162,164,403, 404,405,406,601,602, 603,158,452,453,454, 304,305,401,402	Capacitor, Ceramic Disc,	0.001 μF	50V	+80% -20%	YF.. 020-190-9-012
C-803	Capacitor, Ceramic Disc,	0.0033 μF	50V	+80% -20%	YF.. 020-190-9-013
C-2,5,7,8,9,10,11,12,13,42, 58,64,66,69,78,81,82,85, 96,97,101,102,103,105, 110,117,118,125,130,133, 136,140,141,143,144,145, 159,160,161,168,169,201, 202,203,207,208,301,302	Capacitor, Ceramic Disc,	0.01 μF	50V	+80% -20%	YF.. 020-190-9-015

**CIRCUIT SYMBOL**

**DESCRIPTION**

**DYNASCAN PART NO.**

**CAPACITORS (Continued)**

C-90	Capacitor, Ceramic Disc,	0.022 $\mu$ F	25V	+80% -20%	ZF..	020-213-9-004
C-16,17,21,23,24,26,35,46, 47,56,68,111,113,116,146, 147,206,701,802	Capacitor, Ceramic Disc,	0.039 $\mu$ F	25V	+80% -20%	ZF..	020-206-9-001
C-14	Capacitor, Ceramic Disc,	2 pF	50V	$\pm 0.25$ pF	CH	020-180-9-002
C-104,106	Capacitor, Ceramic Disc,	10 pF	50V	$\pm 0.5$ pF	CH	020-213-9-005
C-109	Capacitor, Ceramic Disc,	9 pF	50V	$\pm 0.5$ pF	RH	020-213-9-006
C-88	Capacitor, Ceramic Disc,	15 pF	50V	$\pm 10\%$	RH	020-207-9-006
C-4	Capacitor, Ceramic Disc,	22 pF	50V	$\pm 10\%$	RH	020-205-9-002
C-50	Capacitor, Ceramic Disc,	56 pF	50V	$\pm 10\%$	RH	020-208-9-002
C-86	Capacitor, Ceramic Disc,	68 pF	50V	$\pm 10\%$	RH	020-196-9-001
C-108	Capacitor, Ceramic Disc,	100 pF	50V	$\pm 10\%$	RH	020-204-9-010
C-87	Capacitor, Ceramic Disc,	150 pF	50V	$\pm 10\%$	RH	020-207-9-008
C-94	Capacitor, Ceramic Disc,	47 pF	50V	10%	UJ	020-207-9-002
C-451	Capacitor, Ceramic Disc,	0.001 $\mu$ F	50V	10%	YB	020-210-9-007
C-54	Capacitor, Ceramic Disc,	0.0047 $\mu$ F	50V	20%	YD	020-204-9-018
C-60,63,65,142	Capacitor, Ceramic Disc,	0.01 $\mu$ F	50V	20%	YD	020-204-9-019
CC-1	Capacitor, Array,	0.01 $\mu$ F x 4,	HA-003	.....		527-077-9-002

**CRYSTALS**

X-1	Crystal,	QX-074,	10.240 MHz	.....		132-027-9-001
XF-1	Crystal Filter,	FL-055,	10.695 MHz	.....		143-011-9-001
CF-1	Ceramic Filter,	FL-009,	455 kHz	.....		140-009-9-001

**MISCELLANEOUS**

	Printed Circuit Board,	PC-407 AB, Main	.....			
	Printed Circuit Board,	PC-399AA, SP. JACK	.....			
	Printed Circuit Board,	PC-408AA, MIKE JACK	.....			
	Printed Circuit Board,	PC-410AB, DC POWER SUPPLY	.....			
	Printed Circuit Board,	PC-301AA, SW	.....			
	Printed Circuit Board,	PC-403AA, CH SW	.....			
	Printed Circuit Board,	PC-367AA, CH LED	.....			
	Printed Circuit Board,	PC-400AA, CLOCK	.....			
	Printed Circuit Board,	PC-300AA, ALARM	.....			
	Printed Circuit Board,	PC-311AA, PHONE	.....			302-346-9-001
S-501	Switch, Rotary	SR-216	CH SW	.....		083-243-9-001
S-701,702	Switch, Push, Dual	SW-158	ALARM/SET	.....		088-047-9-001
S-703,704,705	Switch, Push, Triple	SW-159	FAST/SLOW/HOLD	.....		088-047-9-002
S-304	Switch, Slide,	SW-099	AC-DC	.....		084-065-9-003
S-308,302	Switch, Lever,	SW-151	SP1 - SP1 + 2 - SP2	.....		080-010-9-001
			SWR - CAL - MOD	.....		
S-301,303,306	Switch, Lever,	SW-152	ANL - PA - CB	.....		080-010-9-002
			NB - OFF	.....		
SP-301	Speaker,	SP-003	.....			580-013-9-001
SP-801	Speaker,	SP-054	Clock Alarm	.....		583-001-9-001
M-301	Meter,	MT-160	S/RF	.....		320-100-9-001
M-302	Meter,	MT-161	MOD/SWR	.....		320-100-9-002
	Microphone	MK-075	.....			562-025-9-001

**CIRCUIT  
SYMBOL**

**DESCRIPTION**

**DYNASCAN  
PART NO.**

**MISCELLANEOUS (Continued)**

PL-301	Lamp	PL-065	S/RF .....	400-057-9-001
PL-302	Lamp	PL-065	MOD/SWR .....	400-058-9-001
PL-303	Lamp	PL-065	TX .....	400-057-9-002
PL-304	Lamp	PL-065	RX .....	400-058-9-002
J-301	Connector,	JK-035	ANT .....	772-027-9-001
J-302	Jack,	JK-052	DC PWR .....	762-020-9-001
J-303,401,402,403	Jack,	JK-001	REC/PA SP/EXT SP1/EXT SP2 .....	773-077-9-001
J-451	Jack,	JK-058,	Mike .....	773-073-9-001
J-601	Jack,	JK-005,	PHONES .....	773-094-9-001
P-301	Plug,	PG-003,	SP BOX .....	775-034-9-001
TP-1,2,3,4,5,6	Terminal	TP-029,	Test Point .....	757-033-9-001
F-301,302	Fuse,	2A	250V, FS-012 .....	191-251-3-002
	Fuse Hodler,	FH-002	.....	742-035-9-001
	Insulator,	YD-039,	IC-1 .....	342-046-9-002
	Insulator,	YD-033,	TR-201 .....	345-050-9-002
	Insulator,	YD-043,	TR-11 .....	342-047-9-001
	Insulator,	YD-042,	TR-10 .....	342-047-9-002
	Clamper, Wire,	YY-047	.....	380-278-9-001
	Clamper, Lead,	YY-049	.....	380-284-9-002
FC-501	Flat Cable,	WF-114	.....	426-046-9-001
FC-502	Flat Cable,	WF-116	.....	426-046-9-002
FC-701,702	Flat Cable,	WF-115	.....	426-046-9-003
	Chassis		.....	
	Cover, Top		.....	253-068-9-001
	Cover, Bottom		.....	252-026-9-001
	Chassis, Front		.....	254-032-9-001
	Panel, Side (R)		.....	263-009-9-001
	Panel, Side (L)		.....	263-009-9-002
	Panel, Rear		.....	262-022-9-001
	Holder, Lamp		.....	251-357-9-001
	Holder, Meter		.....	251-357-9-002
	Holder, Switch		.....	251-357-9-003
	Angle, Switch		.....	251-227-9-001
	Heat Sink		.....	747-052-9-002
	Heat Sink		.....	747-065-9-001
	Holder, Integrated Circuit		.....	762-021-9-001
	Holder, Transformer		.....	251-173-9-003
	Lug Terminal		.....	740-024-9-001
	Hanger, Microphone		.....	741-074-9-001
	Cabinet, Wood		.....	290-004-9-001
	Panel, Front		.....	255-174-9-001
	Knob Channel		.....	751-168-9-001
	Knob		.....	751-168-9-004
	Knob, Push Switch		.....	751-168-9-007
	Bushing, Phone Jack		.....	763-114-9-001
	Control Nameplate		.....	600-049-9-001
	Control Nameplate		.....	600-049-9-002
	Brand Nameplate		.....	600-049-9-003
	FCC Nameplate		.....	
	Label, Fuse		.....	
	Label, Caution		.....	
	Label, Caution		.....	483-337-9-002
	Label, Serial Number		.....	

CIRCUIT  
SYMBOL

DESCRIPTION

DYNASCAN  
PART NO.

MISCELLANEOUS (Continued)

Label, Production Date.....		
Label, Warning .....		484-035-9-001
Display Plate, Clock/RX-TX .....		763-115-9-001
Optical Filter, LED CLOCK .....		763-115-9-002
Plate, Receive display.....		763-115-9-003
Plate, On the air display.....		763-115-9-004
Optical Filter, CH display .....		763-115-9-005
Protection Cover, Front Panel .....		502-113-9-001
Protection Cover, Front Panel .....		502-113-9-002
Cushion, Meter .....		502-113-9-003
Cushion, Meter .....		502-113-9-004
Washer, Rubber .....		347-075-9-001
Washer, Bakelite .....		347-080-9-001
Spacer, Alarm PCB .....		759-085-9-001
Screw, Bind Head 2.6 x 4 m/m .....		634-073-9-001
Screw, Bind Head 3 x 5 m/m .....		634-067-9-002
Screw, Bind Head 3 x 8 m/m .....		634-067-9-001
Screw, Bind Head 4 x 10 m/m .....		634-084-9-001
Screw, Bind Head 5 x 14 m/m .....		634-105-9-001
Screw, Flat Head 3 x 6 m/m .....		634-081-9-004
Screw, Round Head 3 x 6 m/m .....		634-105-9-002
Screw, Bind Head 3 x 8 m/m .....		710-032-9-002
Screw, Bind Head 3 x 6 m/m .....		710-021-9-004
Screw, Bind Head 3 x 14 m/m .....		710-032-9-001
Screw, Bind Head 3 x 16 m/m .....		710-043-9-001
Screw, Round Head 3.1 x 10 m/m .....		634-105-9-003
Screw, Pan Head 3 x 6 m/m .....		634-051-9-001
Nut, Flange 4 m/m .....		653-037-9-001
Washer, 3 m/m .....		724-021-9-001
Washer, 5 m/m .....		724-031-9-001
Foot, Rubber, 25 x 17 m/m .....		381-058-9-001
Spring, Channel Knob .....		763-084-9-004
Stopper, Cord .....		763-111-9-002
Rivet, FCC Nameplate .....		
Lug Terminal .....		
Accessory Box .....		500-382-9-001
Display Box .....		500-382-9-002
Shipping Box .....		
Protection Pad (R) .....		503-130-9-001
Protection Pad (L) .....		503-142-9-002
Protection Pad (C) .....		503-157-9-001
Protection Pad Paper .....		502-113-9-005
Instruction Manual .....		480-235-9-001
Circuit Diagram/Bill of Material .....		499-141-9-001
Warranty Card .....		
Service Station Card .....		
FCC Form 505 .....		
FCC Form 555 B .....		
FCC Rule Part 95 .....		
AC Cord, WZ-022 .....		420-027-9-001
Cap Connector, YY-008 .....		
DC Cord, W-070101, DC PWR.....		426-044-9-002
Clamper, Wire, YY-023 .....		
Snap Bushing, YY-024 .....		
Snap Bushing, YY-025 .....		

499-141-9-001



CIRCUIT  
SYMBOL

DESCRIPTION

DYNASCAN  
PART NO.

**SPEAKER BOX**

Holder, Right Panel .....	251-357-9-004
Holder, Left Panel .....	251-357-9-005
Cover, Bottom .....	253-068-9-002
Panel, Rear .....	253-068-9-003
Plate, Baffle .....	260-165-9-001
Panel, Front .....	255-174-9-002
Speaker Grille (A).....	261-076-9-001
Speaker Grille (B).....	261-076-9-002
Cabinet, Wood .....	290-004-9-002
Plate (A) .....	260-165-9-002
Plate (B) .....	260-165-9-003
Plate (C) .....	260-165-9-004
Plate (D) .....	260-165-9-005
Cover, Cloth , Lever Switch .....	253-068-9-004