

This Manual is provided by
CBTricks.com

Someone who wanted to help you repair your equipment put together this information.

Cobra 135XLR Parts List

If you would like to help us put more manuals online support us.

If you would like to help with this project let us know.

Supporters of CBTricks.com paid for the hosting so you would have this file.

CBTricks.com is a non-commercial personal website was created to help promote the exchange of service, modification, technically oriented information, and historical information aimed at the Citizens Band, GMRS (CB "A" Band), MURS, Amateur Radios and RF Amps.

CBTricks.com is not sponsored by or connected to any Retailer, Radio, Antenna Manufacturer or Amp Manufacturer, or affiliated with any site links shown in the links database. The use of product or company names on my web site is not endorsement of that product or company.

If your company would like to provide technical information to be featured on this site I will put up on the site as long as I can do it in a non-commercial way.

The site is supported with donation from users, friends and selling of the Galaxy Service Manual CD to cover some of the costs of having this website on the Internet instead of relying on banner ads, pop-up ads, commercial links, etc. Thus I do not accept advertising banners or pop-up/pop-under advertising or other marketing/sales links or gimmicks on my website.

ALL the money from donations is used for CBTricks.com I didn't do all the work to make money (I have a day job). This work was not done for someone else to make money also, for example the ebay CD sellers.

All Trademarks, Logos, and Brand Names are the property of their respective owners.

This information is not provided by, or affiliated in any way with any radio or antenna Manufacturers.

Thank you for any support you can give.

COBRA 135 XLR PARTS LIST

SCHEMATIC SYMBOL	DESCRIPTION	DYNASCAN PART NO.
RESISTORS, CONTROLS AND THERMISTORS		
R43, 507	Carbon, 1 ohm 1/4W	002-104-5-010
R173, 174	Mold, 1 ohm 1/8W	013-027-9-001
R92A	Metallic Film, 4.7 ohm 2W	013-007-9-001
R92B	Metallic Film, 6.8 ohm 2W	013-027-9-002
R92C	Metallic Film, 3.3 ohm 2W	013-027-9-003
R92D	Metallic Film, 8.2 ohm 2W	013-027-9-004
R92E	Metallic Film, 10 ohm 2W	013-027-9-005
R315	Solid, 22 ohm 1/8W	002-108-5-220
R160	Metallic Film, 16 ohm 3W	006-005-5-160
R178	Solid, 68 ohm 1/4W	001-104-5-680
R88	Metallic Film, 82 ohm 1W	013-027-9-006
R4, 5	Carbon, 100 ohm 1/8W	002-108-5-101
R85	Solid, 120 ohm 1/2W	002-102-5-121
R142, 144	Solid, 470 ohm 1/4W	002-104-5-471
R7	Solid, 1000 ohm 1/2W	001-102-5-102
R379~392	Carbon, 1000 ohm 1/8W	002-108-5-102
R96, 343	Solid, 4700 ohm 1/8W	002-108-5-472
R136	Solid, 10 Kohm 1/8W	002-108-5-100
R373	Solid, 150 Kohm 1/8W	002-108-5-154
R172	Solid, 47 Kohm 1/8W	002-108-5-470
R356, 375	Carbon, 15 Mohm 1/4W	001-104-5-156
R372	Block, 100 Kohm x 8 1/4W	013-027-9-007
R506	Solid, 2.2 Mohm 1/2 W	002-102-5-225
R46	Thermister, D33A	004-099-9-002
R86, 89	Semi Fixed 100 ohm	008-206-9-004
R10, 322, 502	Semi Fixed, 1 Kohm	008-206-9-010
R134	Semi Fixed, 2 Kohm	008-325-9-001
R72	Semi Fixed, 5 Kohm	008-206-9-005
R9, 12, 49, 317	Semi Fixed, 10 Kohm	008-206-9-008
R130	Semi Fixed, 20 Kohm	008-206-9-009
R324, 328	Semi Fixed, 30 Kohm	008-206-9-002
R8	Variable, 20 Kohm (W/S)	008-325-9-002
R51, 326	Variable, 20 Kohm	008-300-9-002
R120	Variable, 50 Kohm	008-300-9-004
R90, 143	Variable, 5 Kohm 50 Kohm	008-325-9-003

CAPACITORS AND TRIMMERS

C18, 63, 307	Ceramic, SL 1P	020-097-9-009
C62, 305, 331	Ceramic, SL 2P	020-097-9-004
C44, 58, 64	Ceramic, SL 3P	020-097-9-014
C45	Ceramic, SL 5P	020-097-9-007
C9, 86, 311, 322, 329, 340	Ceramic, SL 10P	020-097-9-010
C57	Ceramic, N470 10P	020-170-9-001
C303, 308	Ceramic, N750 10P	020-097-9-003
C302	Ceramic, N220 15P	020-157-9-001
C56, 82	Ceramic Trimmer, 20P	028-026-9-001
C13, 39, 328, 351	Ceramic, SL 22P	020-097-9-006
C304	Ceramic, N750 22P	020-173-9-007
C12, 83	Ceramic, N220 22P	020-157-9-002
C14, 161	Ceramic, SL 33P	020-157-9-003
C309	Ceramic N750 33P	020-174-9-002
C324	Ceramic, SL 47P	020-097-9-011

SCHEMATIC
SYMBOL

DESCRIPTION

DYNASCAN
PART NO.

CAPACITORS AND TRIMMERS (Continued)

C318, 320, 321, 335, 336	Ceramic, N220 47P	020-088-9-002
C5, 69, 76, 85, 105, 110, 141, 142	Ceramic, SL 100P	020-097-9-004
C310	Ceramic, N750 100P	020-173-9-003
C84	Ceramic, SL 150P	020-097-9-002
C326, 334	Ceramic, 220P	020-191-9-001
C6, 8	Ceramic, SL 220P	020-097-9-009
C7, 72, 79	Ceramic, SL 330P	020-097-9-013
C2, 3, 21, 59, 65, 119, 182, 349, 366~368	Ceramic, 470P	020-097-9-022
C505, 506	Ceramic 1000P (UL)	020-174-9-002
C1, 4, 10, 15, 17, 19, 20, 50, 54, 88, 151, 325, 332, 363	Ceramic, 2200P.....	020-088-9-007
C16, 22, 24, 27~29, 32, 37, 51, 55, 60, 61, 66~68, 70, 73, 75, 78, 81, 87, 91, 96, 97, 99, 103, 112, 116, 120, 126, 131~140, 143, 148, 149, 152~154, 158~160, 163, 168, 169, 173~175, 177~181, 185~187, 189, 196, 197, 315, 316, 319, 323, 330, 333, 359, 360, 503, 504	Ceramic, 4700P	020-088-9-008
C167	Ceramic, 10000PF/50V	020-088-9-009
C346	Mylar Film, 1000pF/50V	025-112-9-002
C25, 26, 31, 48, 52, 100, 101, 118	Mylar Film, 0.01 μ F/59V	025-060-9-001
C102	Mylar Film, 0.022 μ F/50V.....	025-071-9-002
C11, 71, 74, 80, 89, 121, 157, 164, 166, 195, 314, 337, 344, 353, 357, 358, 364	Mylar Film, 0.033 μ F/50V	025-060-9-003
C345x2	Mylar Film, 0.047 μ F/50V.....	025-128-9-001
C327	Mylar Film, 0.1 μ F/50V	025-060-9-004
C106, 107, 111, 115, 155	BC, 0.1 μ F/25V	033-017-9-001
C365	Tantalum, 0.22 μ F	027-028-9-001
C23	Tantalum, 0.33 μ F	027-029-9-001
C34, 46, 49, 90, 92, 114, 127, 199, 200	Electrolytic, 1 μ F/50V	022-076-9-001
C104, 339x2	Tantalum, 3.3 μ F	027-020-9-001
C33, 35, 93	Electrolytic, 3.3 μ F/50V	022-076-9-002
C36, 38, 47, 53, 77, 95, 108, 117, 122, 130, 165, 301, 306, 338, 361	Electrolytic, 10 μ F/16V	022-076-9-003
C94	Electrolytic, 10 μ F/16V (Both side lead)	022-162-9-001
C30, 98, 109	Electrolytic, 33 μ F/16V	022-074-9-005
C123, 343	Electrolytic, 100 μ F/10V	022-074-9-010
C129, 501	Electrolytic, 100 μ F/16V	022-091-9-001
C341	Electrolytic, 220 μ F/10V	022-076-9-010
C113	Electrolytic, 1000 μ F/25V	022-150-9-002
C124, 125	Electrolytic, 1000 μ F/16V	022-150-9-003
C502	Electrolytic, 4700 μ F/25V	022-092-9-001
C502A	Electrolytic, 2200 μ F/25V	022-129-9-001

COILS, CHOKES AND TRANSFORMERS

T1	RF Transformer, 25099	066-028-9-001
T2, 3, 10, 11, 12	RF Transformer, L1641	066-013-9-002
T4, 5	RF Transformer, 25091	066-028-9-002
T6	RF Transformer, L1839	066-029-9-001
T7	RF Transformer, L1786	066-015-9-001
T8	RF Transformer, L1787	066-015-9-002
T9	RF Transformer, L1785	066-015-9-003
T13	AF Transformer	061-029-9-001
T301, 302	RF Transformer, 25093	066-028-9-003
T303	RF Transformer, 25094	066-028-9-004
T501	Power Transformer	065-076-9-001

SCHEMATIC
SYMBOL

DESCRIPTION

DYNASCAN
PART NO.

COILS, CHOKES AND TRANSFORMERS (Continued)

L1, 2	RF Coil, L1904-G1	044-025-9-005
L3	RF Coil, 25104	041-096-9-001
L4	RF Choke Coil, 332	042-022-9-002
L5	RF Coil, 25100	041-096-9-002
L6, 8	RF Choke Coil, 25101	042-027-9-001
L7	RF Coil, 25105	041-096-9-003
L9	RF Choke Coil, L1845	042-009-9-003
L10	AF Choke Coil	042-022-9-003
L11	RF Coil, L1904-G4	044-049-9-001
L12	RF Choke Coil, L1122	042-009-9-061
L13, 14	Choke Coil, L111	042-027-9-002
L301	RF Coil, 25095	041-096-9-004
L302	RF Coil, 25096	041-096-9-005
L303	RF Coil, 25097	041-096-9-006
L304	RF Coil, 25090	041-084-9-003
L501, 502	Toroidal Coil	042-027-9-003

DIODES, TRANSISTORS AND INTEGRATED CIRCUIT

IC1	SV10052 (IC)	307-107-9-002
IC2	TA7064P (IC)	307-107-9-001
IC3	TA7205P (IC)	307-107-9-003
IC301, 303	TC5081P (IC)	307-107-9-004
IC302	TC5082P (IC)	307-107-9-005
IC304	TC5080P (IC)	307-107-9-006
CD1, 2, 8, 13, 14	IN60 (Diode)	150-001-9-005
CD3, 5~7, 9~11, 15~17, 19, 25~31, 37, 43~46, 48, 50~54, 56~58, 62, 63, 64, 304, 305, 307, 310, 312~315	IS1588 (Diode)	151-051-9-001
CD12	SVC0050-BR (LED)	158-017-9-001
CD20~23	1N60FM-PAIR (Diode)	157-007-9-001
CD24~36, 49, 60, 61, 502	1S1885 (Diode)	151-030-9-005
CD47, 303, 308, 309	RD6.2FB (Diode)	152-047-9-001
CD301, 302	1S2789 (Diode)	153-009-9-001
CD306	1S1658 (Diode)	151-030-9-004
CD316, 317	TLR308 (LED)	158-017-9-002
CD501	RD6.8FB (Diode)	152-042-9-002
CD503~506	1R5BZ61 (Diode)	157-008-9-001
Q7, 8, 9A, 9B, 10, 16, 17, 18, 19, 23, 28, 304, 307, 308, 310~317, 319, 501	2SC372-Y (Transistor)	176-042-9-003
Q2	3SK40 (Transistor)	182-049-9-001
Q3	2SC784-R (Transistor)	176-056-9-003
Q4, 5	2SC380-O (Transistor)	176-082-9-001
Q6, 503	2SC735-O (Transistor)	176-031-9-001
Q11	2SC1166-Y (Transistor)	176-056-9-005
Q12, 14	2SC1173 (Transistor)	172-026-9-001
Q13	2SC1678 (Transistor)	172-028-9-001
Q15	2SC1307 (Transistor)	176-044-9-001
Q20	2SC732-BL (Transistor)	176-056-9-006
Q21, 22, 306	2SA495-O (Transistor)	177-019-9-003
Q24, 25	2SA950-Y (Transistor)	177-032-9-001
Q27	2SB435-Y (Transistor)	175-010-9-001
Q301, 302, 303	2SK19-GR (Transistor)	182-029-9-001
Q305, 309	2SC387A (Transistor)	176-044-9-003
Q318	2SD235-O (Transistor)	172-031-9-003
Q502	2SD235-Y (Transistor)	172-010-9-001

SCHEMATIC SYMBOL	DESCRIPTION	DYNASCAN PART NO.
CRYSTALS		
X1	Crystal (7.8025 MHz)	133-017-9-001
X301	Crystal (17.05625 MHz)	133-017-9-002
X302	Crystal (5.12 MHz)	133-012-9-001

SWITCHES		
S1, 3, 5	Uni Switch	088-012-9-002
S4	Uni Switch	088-012-9-001
S301	Rotary Switch	083-213-9-001
S501	Push Switch	088-010-9-001
S502	Push Switch	088-010-9-002

MISCELLANEOUS		
J1	Antenna Jack	772-002-9-001
J2	Microphone Jack	773-057-9-001
J3, 4	PA, EXT Jack	773-084-9-001
J505	Power Connector	773-039-9-003
K1	Relay	441-010-9-001
K2	Relay	441-020-9-001
M1	Meter	320-036-9-001
MK1	Microphone	562-003-9-001
P1	Microphone Plug	775-029-9-001
PL1	Lamp (Meter)	400-023-9-001
PL3, 4, 5	Lamp (Mode)	400-022-9-001
PL1A	Lamp Socket	752-008-9-001
SP1	Speaker	580-012-9-001
U1	Crystal Filter	143-007-9-001
U501	Digital Clock	465-001-9-001
W1	DC Power Cord	420-014-9-001
W2	AC Power Cord	420-014-9-002
F1, 501	Fuse, 3A	191-251-9-003
F502	Fuse, 1A (Pig tail)	193-251-3-001
FS501	Fuse Holder	742-028-9-001
	Knob for Channel	751-157-9-001
	Knob for Volume ETC	751-092-9-004
	Knob for RF GAIN	751-157-9-002
	Knob for DYNA MIKE	751-157-9-003
	Knob for Clock Time	751-085-9-003
	Knob for Clock Time Set	751-085-9-004
	Knob for Power	751-157-9-004
	Knob for Auto	751-157-9-005

NOTE: Standard value resistors and capacitors are not listed, values may be obtained from schematic diagram.

Specify serial number when ordering replacement parts.